卡丽KARAT。 安装说明书 INSTALLATION STRUCTIONS

赛琳娜单把单孔脸盆龙头 SELINA LAVATORY FAUCET, SINGLE HOLE 21906T-CP

BEFORE YOU BEGIN

Please read these instruction carefully familiarize yourself with the required tools,materials,and installation sepuences. Follow the sections that pertain to your patticular installation. This will help you avoid costly mistakes. In addition to proper installation, read all operating and safety instructions.

All infromation in these instructions is based upon the latest product infromation available at the time of publication. Karat reserves the right to make changes in product characteristics, packageing, or availability at any time without notice.

These instructions contain important care, cleaning, and warranty information, please leave instructions for the consumer

NOTES:

Flush the water supply pipes thoroughly to remove debris. Work pressure:0.5~5kgf/cm²

安装之前

请仔细阅读说明书,熟悉所需工具、材料和安装顺序,参 照相关章节完成您所需的安装,以避免昂贵的损失,除了 正确的安装外,请详阅所有的操作和安全说明。

本说明书所含的一切资料均以印刷时所有的最新产品为准,卡丽公司保留权利随时更改产品特性、包装或供应情况,恕不另行通知。

本说明书也包含了有关保养、清洁及产品担保等重要信息-请交予用户保存。

注意事项:


一定要先彻底冲洗供水管以及清除管道中的杂质。适用工作水压: 0.5~5kgf/cm²


ROUGHING-IN

Unit:mm

尺寸图

单位 毫米





INSTALLATION


1 HOW TO INSTALLATION THE FAUCET Put the washer into the bottom of the faucet body through the flexible hoses and mounting stud.

安装

1 安装龙头 把垫圈通过软管和固定螺栓装到龙头底部。

20170926 -1-

Insert the installation bolt into the lavatory hose. Position the faucet. From underside of the lavatory, and secure the faucet with the nut. 把供水软管插到脸盆孔中,调整龙头位置,从脸盆的下方用螺母上紧以固定龙头。



INSTALLATION CHECKOUT

安装后检查


Ensure that all coupling nuts are tight. Ensure that the lever handle is in the close position.

Turn on the main water supply, and check for leaks. Repair as needed.

Remove the aerator assembly and hand spray. Run hot and cold water through the faucet for about a minute to remove any debris. Check for leaks. Remove any debris from the aerator assembly. Shut the faucet off, and reinstall the aerator assembly and hand spray.

确保所有衔接螺母都已拧紧,确保手柄处在关闭的位置, 开启主水源,检查是否有漏水,如有请重新拧紧。

取下起泡器组件和花酒。把冷热水都打开,让水流出一分钟以清除杂质,检查漏水。清洗起泡器并关闭龙头,装回起泡器组件和花酒。



HANDLE OPERATION

Lift the handle gently. Turn Left for hot water. Turn Right for cold water.

将手柄轻轻提起,左手为热水,右手为冷水。

CLEANING INSTRUCTIONS

清理说明

All finishes: clean the finish with a mild soap and warm water. wipe entire surface complately dry with a clean soft cloth. Many cleaners may contain chemicals, such as ammonia chlorine, toilet cleaner etc., Which could adversely affect the finish and are not recommended for cleaning.

Don't use abrasive cleaner or solvents on karat faucets and fitting.

适用于所有加工处理过的表面: 以中性肥皂水清洗镀层表面,再以干净的软布彻底擦干整 个表面。许多清洁剂,比如每次 个表面。许多清洁剂,比如每次 对电镀表面造成伤害, 切勿使用。

有腐蚀性的清洁剂或溶剂不可使用于卡丽的水龙头及其附 件上。

FIVE -YEARS WARRANTY

五年有限担保

Our company provides five years warranty for its faucets valve to be leak and drip free during normal residential use. We also warrant all other aspects of its faucets to be free of defects of materrial and workmanship during normal residential use for one year. Our company will be responsible any problens caused by manufacturing defects provided with the invoice. Our company will, at its election, repair, replace or make appropriate adjustment where our company inspection discloses any such defects occurring in normal usage within warranty.

The warranty, including products, is limited clearly. Our company is not responsible for other damages appeared after the warranty. Also, the warranty dose not cover problems arising from labor charges, incorrect use and installation.

本产品自购买之日起,在正常使用下任何由阀芯造成的龙头滴漏现象,我司将提供长达五年的质量担保,同时对正 常使用下的龙头制造和质料上的瑕疵提供一年的质量担保。 在质保期内,凭购货发票,我司将免费承担由制造质量引 起的任何问题。经核查后,我司有权决定是修理、更改、 还是做适当的调整。

这里的担保,包括产品都已明确地限制在该担保期内。本 公司对以后出现的损坏不负有任何责任。担保也不包括外观损伤,使用不当及未按说明书安装的损失。

Shanghai Kohler International Trade Co., Ltd.

Address: Room 324, 2 Xinlin Rd, Waigaoqiao Free Trade Zone, Shanghai

Tel: 021-26062000 Postcode: 200131

上海科勒国际贸易有限公司

地址:上海市外高桥保税区新灵路106号2号楼324室

电话: 021-26062000

邮编: 200131

卡丽KARAT。 维修零件图 SERVICEPARTSPAGE

赛琳娜单把单孔脸盆龙头 SELINA LAVATORY FAUCET, SINGLE HOLE 21906T-CP

